

01
Getting to know your device

- Front -

02
Charging Base

- Side -

03
Charging Base

- Back -

04
Charging Base

- Front -

05
Charging Base

- Back -

06
Charging Base

- Bottom -

03
Put SIM card

The SIM card is not included in the package. A Nano SIM card is available from the user's local operator.

- Unscrew the back cover and remove the cover.
- Insert SIM card and make sure it's activated with credits.
- Put the cover back and tighten the screws.

TIP Before installing the SIM card, check if the SIM card has PIN code or not, if yes, please use a cell-phone to unlock the card's PIN code.

04
Charging your device

There are two ways to charge your device.

4.1/Charging by magnetic USB cable

- When placing magnetic USB cable to device charging contacts make sure it is positioned correctly.
- The power indicator (red light) should blink when charging and solid when fully charged.

4.2/ Charging by charging base

- Place the device on the charging base
- Connect the USB cable from charging base to the AC adaptor.

The charging base light will glow when charging and solid when fully charged.

TIP For the first time use, please fully charge the battery for around 2-3 hours

TIP The charging base is equipped with 2000mAh back up battery, which can charge the device when the electricity is off at home or when traveling.

TIP When the battery level falls below 20% it will send low battery warning message to people on the contact list via text message or APP.

05
Switching on and off device

There are two ways to charge your device.

- To turn on the device:** press the side call button for 1 second, all the LEDs will flash rapidly. Device can also be turned on automatically by charging via magnetic USB cable or put it into the docking station.
- To turn off the device:** press and hold the side button and SOS button together for 3 seconds until the LEDs off.

01 02 03 04 05 06 07 08 09 10

06
What do the lights mean?

• 4G signal indicator--Green

Green	Light shows a single flash rapidly every 3 seconds	Light shows a double flash rapidly every 3 seconds
Means	The device is fixed the 4G signal	The device is registered to the 4G network

• Positioning indicator--Blue

Blue	Light shows a single flash rapidly every 3 seconds	
Means	The device has no latest location fix	
Blue	Light shows a double flash rapidly every 3 seconds	Light Off
Means	The device has latest location fix	The device is not fixing the latest location

• Power indicator--Red

Red	Red ON (solid)	Red shows a double flash rapidly every 3 seconds
State	Device has been fully charged	BLE connected
Red	Red Blinking Quickly	Red Off or blinking slowly
State	Battery power is lower than 20%	The device is charging

07
Activating an SOS Alarm

When you need help, press the SOS button Down for 3-4 seconds till you hear a voice prompt of activating an SOS alarm. this starts the sequence of "help me!" text message send to your emergency contact numbers followed by the outgoing calls.

• If the device fails to connect to the first number, it will call the second number after delay of 10 seconds. In case the second number fails to be connected as well, the system will connect to the third number etc.

TIP Please remember to program emergency contact numbers. It is not mandatory for all ten authorized numbers to be set, however a minimum of one must always be set.

TIP Please be patient during the call sequence. There can be short delays as the alarm calls phones who maybe out of range or delivered to people's voicemail.

08
Getting a GPS fix

GPS

- To get an initial fix for the GPS features, use outdoors or near a window so the device can get a fix on the satellites. This could take few minutes according to your environment.

09
Fall down alarm

- Device detects a fall and it will automatically send an alarm to emergency contacts.
- Due to the daily life activities (like some sports, sit back on a coach, etc), device may detect a fall incorrectly, this situation may cause false alarm. However, users can manually cancel the fall alert by pressing SOS button during its beeping.

TIP Very Important: Because it still has few chances for the non-detected falling down, we still strongly recommend user to press SOS button when it has emergency situation.

10
Making a Phone Call

- To make a call, press side call button for 3 seconds and you will hear a beep, and then it will dial the second number.
- To end the call, press the SOS button.

11
Bluetooth connection

- To be able to connect charging base via Bluetooth, the device must be added to the whitelist of the docking station.

Specification:

- Dimension: 61mm*44mm*16mm
- Weight: 40g
- Battery: Rechargeable, 3.7V,850mAh
- Charging voltage: 5V DC
- Waterproof: IP67
- 4 locating technologies: GPS, BLE, WIFI, LBS

Cautions:

Please comply with the instructions to extend the unit life:

- Don't use & store the unit in dusty places.
- Don't put the unit in overheated or over cooled places.
- Clear the unit with a piece of dry cloth. Don't clean in chemicals, detergent.
- Don't disassemble or refit the unit.
- Using other batteries will cause unwanted situation.

Personal Mobile Alarm Device

Quick Start Guide

11 12 13 14 15 16 17 18

